


196 Brake-spring pliers



Description:

- For removing shoe springs.
- Suitable for right-handed and left-handed working.



	Length L [mm]	Diameter [mm]	Head Width B [mm]	Weight [Kg]
196.KS	485.0	5.0	100.0	1.2
196.TS	350.0	3.0	83.0	0.58